

# Operating Instructions for the Box Radio

Call Sign: Sandy

1. Power on – Turn ‘volume’ control clockwise
2. Wait until display shows channel 16
3. Press 

SCAN MEM
-------------

 and 

MON 1/25
-------------

 buttons simultaneously
4. Select channel ‘-1’ for channel M (37)
5. Use Channel selection knob for other private channels

Radio Display	Corresponding Channel
-1	Channel 37 (M)
-2	M2
-3	46
-4	47